Bed disassembly instructions



Tools you will need

No. 13 spanner or adjustable Large Philips screwdriver

Instructions

1. With the mattress removed and the mechanism in the raised position, remove the nuts from the gas struts (7) on both sides

- 2. With the mechanism now disengaged, lay it flat
- 3. Remove nuts (6) and (4) on both sides
- 4. The mechanism is now disconnected from the base of the bed and can be lifted out.
- 5. Remove all screws from the both end panels; you will now have 4 separate side sections.

